



	Artikelnummern	Funktionen				
						
ALFA ROMEO Brera, 159	65003	✓	✓	–	✓	✓
AUDI A3 03~08, A4 01/00-2007, TT 06~08; mit ISO	65009	✓	✓	✓	✓	✓
AUDI A3 03~08, A4 01/07-2008, TT 06~08; mit Quadlock	65010	✓	✓	✓	✓	✓
BMW 1 E81/87, 3 E90, 5 E60, 6 E63, 7 E65, Mini R56	65015	✓	✓	–	✓	✓
CITROËN C2 03~, C3 02~, C4 06~, C5 MK2 05~, C8 06~; mit Quadlock	65020	✓	✓	–	✓	✓
CITROËN C2 03~, C3 02~, C4 06~, C5 MK2 05~, C8 06~; nur Radiovorbereitung	65021	✓	✓	–	✓	✓
FIAT Grande Punto 06~, FIAT 500 07~	65025	✓	✓	–	✓	✓
MERCEDES A-W169 05~, B-W245 05~, C-W203 05~; mit Quadlock	65035	✓	✓	–	✓	✓
OPEL Astra, Corsa, Tigra, Vectra, Antara, Agila, Signum; ab 04 mit Quadlock	65070	✓	✓	–	✓	✓
PEUGEOT 207 06~, 307 05~, 308 07~, 407 05~, 807 05~; mit Quadlock	65020	✓	✓	–	✓	✓
PEUGEOT 207 06~, 307 05~, 308 07~, 407 05~, 807 05~; nur Radiovorbereitung	65021	✓	✓	–	✓	✓
RENAULT Clio 05~, Laguna 05~07, Megane 05~08, Modus 05~, Scenic 05~, Twingo 07~	65040	–	✓	–	✓	✓
SEAT alle mit Quadlock ab 2005	65045	✓	✓	–	✓	✓
ŠKODA Octavia 04~, Roomster 07~; mit Quadlock	65048	✓	✓	–	✓	✓
VW Golf 5 04~, Passat 04~, Touran 04~, Polo 04~, Jetta 04~, Eos 06~, Tiguan 07~	65060	✓	✓	–	✓	✓

Radiospezifisches Adapterkabel wird benötigt (650XX):

ALPINE = 65108, BLAUPUNKT = 65104, CLARION = 65109, JVC = 65103, KENWOOD = 65106, PANASONIC = 65101, PIONEER = 65105, SONY = 65105, ZENEC = 65102